26LE30Q HDTV QUICKSTART GUIDE

Before You Begin

- Verify all of the contents of your pack
- Review safety guidelines in User's Manual
- Place LCD TV so the rear connectors are accessible
- Install AAA batteries into the ELEMENT Remote Control
- Write down your 26LE30Q Serial Number (located on the back)

Contents:

Remote Control

Includes 2xAAA Batteries

Power Cord

Documents

User Manual, Warranty Card , Warranty Registration and Quickstart Guide

The Best Connection:

We highly recommend you use HDMI and ANT(DTV) whenever possible . Please keep in mind however that not all components are capable of this type of connection. Our color-coded chart will help explain which components are capable of connecting in HDMI and ANT (DTV). To receive HDMI or component video must be used. To receive HD programs from an antenna use ANT (DTV) input. Standard TV, AV or S-Video cannot pass HDTV signals.

Four Easy Steps

Simply follow our color-coded Step Charts and you're done

1) Choose items to connect to your 26LE30Q

- Determine which type of Signal Source and any Additional Equipment you wish to connect to your 26LE30Q
- The colored dots under each Signal Source and Additional Equipment indicate which type of connections you may use to connect to your 26LE30Q

2) Choose Equipment connection methods

- Using the colored dots from Step One, follow the row across to Step Two to match up the colored dots to the same colored connection method.
- Chose ONLY one method for each piece of equipment.

3) Select cables and make connection

- Once you have determined the connection methods from Step Two, follow the row to Step Three to determine what a kind of cables you need and what the connections look like on your equipment.
- Following the color-coded system, use the appropriate cables and connect your Signal Source and Additional Equipment to the color-coded inputs on your 26LE30Q (Refer to Connection Map at bottom of page.)
- Once connected, turn on your 26LE30Q and all your equipment.

4) Use your 26LE30Q



*RF Cable ,HDMI Cable, VGA Cable , Audio mini-jack, Component Cable and Coaxial Splitter are not included.

Rear Connectors Instruction



INPUT Menu



© 2009 ON Corp US, INC.

385mm

560mm

ELEMENT ELECTRONICS

Program your TV (continued)

Programming your 26LE30Q is a simple TWO STEP process.
All you need is your Remote Control

STEP 1

If you connected your Signal Source to the TV (Regular Cable/ Antenna),go to STEP 2a.

STEP 1

If you connected your Signal Sour to the TV (Digital Antenna/Cable), go to STEP 2b

STEP 2a — TV (Regular Cable/Antenna)

On your Remote Control...

1. Press the [MENU] button to show the ON SCREEN DISPLAY menu.
2. Press the [▲/▼] button to enter the [SETUP]
3. Press the[ENTER] button to select either AIR,CABLE, CABLE HRC, CABLE IRC AND CABLE AUTO
4. Press the [▲/▼] button to highlight [AUTO CH Search] to scan the available channels
5. Use the [▶] button to start the scan, Scanning for available channels could take several minutes.
6. Once scanning is finished, programming is complete.
7. Press [MENU] button until ON SCREEN DISPLAY menu disappears.





For advance set ups, refer to your 26LE30Q User Manual

STEP 2b — DTV (Digital Cable/Antenna)

On your Remote Control...

1. Press the [MENU] button to show the ON SCREEN DISPLAY menu.
2. Press the [▲/▼] button to enter the [SETUP]
3. Press the[ENTER] button to select either AIR,CABLE, CABLE HRC, CABLE IRC AND CABLE AUTO
4. Press the [▲/▼] button to highlight [AUTO CH Search] to scan the available channels
5. Use the [▶] button to start the scan, Scanning for available channels could take several minutes.
6. Once scanning is finished, programming is complete.
7. Press [MENU] button until ON SCREEN DISPLAY menu disappears.





For advance set ups, refer to your 26LE30Q User Manual

385mm

560mm